

User machine menu tree

MACHINE LEVEL	Gravograph IS700 VERSION XX.XX 1								
Upgrade version		Upgrade version	receiving...						
Serial transmission	<input checked="" type="checkbox"/>	Baud rate	Parity	Data bits	Stop bits	Handshake			
machine Configuration		Language	machine	Machine nr	Transfer lock	Display unit	X screw ratio	Y screw ratio	Cylinder ratio
Converting and reference		Unit conversion	XY-plan						
Default configuration		Default configuration							
Test and automaton		Automaton	Automaton O/N						
		Cycle	Cycle O/N						
		Test	Test O/N						
ENGRAVING LEVEL	<READY TO RECEIVE>								
Save the configuration (3 seconds)	<input checked="" type="checkbox"/>	Save configuration	Saving ...						
Plate		Origin	Origin X	Origin Y					
		Dimensions	Dimensions X	Dimensions Y					
		Ratio	X ratio	Y ratio					
		Position	Position						
		Cylinder at.	Diameter	Shift spindle in cylinder at. axis	C.A Switch	Length	Height		
Recall default parameters (3 seconds)		Restore factory par.	restoring...						
Zref		Zref							
Engraving speed		Engraving speed							
Engraving depth		Depth							
Z approach speed and XY dwell-time		Z axis speed	X,Y dwell						
Passes		Passes	Engraving speed	Depth					
Z stroke		Z stroke							

Comment : The machine level can only be accessed once the machine is switched on. Access is given for 3 seconds.